


# IMPORTANT

## BEATER INSTRUCTIONS

Your Mixer will not  
work correctly unless each beater is placed  
in its proper socket



**ROUNDED BEATER**  
Goes Next To Bowl

**SQUARE-SHAPED  
BEATER**  
(Flat Bottom)  
Goes Toward Center  
of Bowl

For further details, see recipe book section on  
"How To Operate Your Mixer"