
CARE OF MODEL 10 AUTOMATIC MIXMASTER

It is important to follow these instructions about oiling and greasing to insure the most satisfaction from your Mixmaster.

During the first month of use oil motor bearings 1 and 2. Use a good light machine oil. Put 2-3 drops of oil in holes 1, 2. DO NOT PUT MORE THAN ONE DROP OF OIL IN 3 and 4.




Under heavy usage these parts should be oiled once every month. Do not OVEROIL. If bowl does not revolve freely put a few drops of oil in the bearing of the base, directly under the disc.

All electric motors get warm when running, and warmth will increase as load on motor is increased. The temperature rise causes no harm to mechanical or electrical parts. Cord will discolor motor housing if wrapped around motor while hot.

Note: Always mention Model number when requesting service or parts for MIXMASTER. See model number stamped on bottom of MOTOR.

PARTS FOR MODEL 10 AUTOMATIC MIXMASTER



C72CJ	Mixing Beater (without bowl-speed		Juice spout
	control button)	P21255	Polishing compound for Polisher &
C57CJ	Mixing Beater (with bowl-speed con-		Buffer Attachment (not shown)
	trol button)	P20846	Tube of special Mixmaster Lubricant
G94CJ	Set of 2 mixing beaters (one of each		(used in gear compartment. Not
	above)		shown)
C52CJ	Revolving Platform	15BS	White Glass Juice Extractor Bowl
G19BS	Juice extractor reamer	19CJ	Large White Glass Mixing Bowl
C75BS	Juicer strainer	20 C J	Small White Glass Mixing Bowl

Repairs involving the above parts are simple and easy to make. Other repairs are more complicated, and to insure their being made properly, the MIXMASTER should be returned, transportation charges prepaid, to the nearest authorized Sunbeam Service Agency, or to the factory or dealer from whom it was purchased.

SUNBEAM MIXMASTER PATENTS

1894858	2002333	2070768	2161881	2293701
1926910	2008184	2099050	2165858	2293959
1975949	2013887	2113025	2274480	

Design patents 102148, 120358, 120359, other patents pending.